2019 **Trigger/Jekyll** Owner's Manual Supplement

READ THIS SUPPLEMENT AND YOUR CANNONDALE BICYCLE OWNER'S MANUAL. Both contain important safety information. Keep both for future reference.

cannondale

Safety Messages

In this supplement, particularly important information is presented in the following ways:

Indicates a hazardous situation which, if not avoided, may result in death or serious injury.

NOTICE

Indicates special precautions that must be taken to avoid damage.

The following symbols are used in this manual:

Symbol	Name	Description
A NGUTZ B	NGLI-2 synthetic grease	Apply NGLI-2 synthetic grease.
ACRP CELLA	Carbon gel	Apply carbon gel (friction paste) KF115/
2	Medium-strength removable thread lock	Apply Loctite® 242 (blue) or equivalent.

Cannondale Supplements

This manual is a "supplement" to your <u>Cannondale Bicycle Owner's Manual</u>.

This supplement provides additional and important model specific safety, maintenance, and technical information. It may be one of several important manuals/supplements for your bike; obtain and read all of them.

Please contact your Authorized Cannondale Dealer immediately if you need a manual or supplement, or have a question about your bike. You may also contact us using the appropriate country/region/location information.

You can download Adobe Acrobat PDF versions of any manual/supplement from our website: http://www.cannondale.com

Contacting Cannondale

Cannondale USA Cycling Sports Group, Inc. 1 Cannondale Way, Wilton CT, 06897, USA 1-800-726-BIKE (2453)

Cycling Sports Group Europe B.V Mail: Postbus 5100 Visits: Hanzepoort 27 7575 DB, Oldenzaal, Netherlands

CONTENTS

Safety Information	2-6
Technical Information	7-19
Replacement Parts	28-29
Tightening Torques	30
Maintenance	31
Notes	

Your Cannondale Dealer

To make sure your bike is serviced and maintained correctly, and that you protect applicable warranties, please coordinate all service and maintenance through your Authorized Cannondale Dealer.

NOTICE

Unauthorized service, maintenance, or repair parts can result in serious damage and void your warranty.

Trigger / Jekyll - Owners Manual Supplement

SAFETY INFORMATION

Important Composites Message

Your bike (frame and components) is made from composite materials also known as "carbon fiber."

All riders must understand a fundamental reality of composites. Composite materials constructed of carbon fibers are strong and light, but when crashed or overloaded, carbon fibers do not bend, they break.

For your safety, as you own and use the bike, you must follow proper service, maintenance, and inspection of all the composites (frame, stem, fork, handlebar, seat post, etc.) Ask your Cannondale Dealer for help.

We urge you to read PART II, Section D. "Inspect For Safety" in your <u>Cannondale Bicycle Owner's Manual</u> BEFORE you ride.

You can be severely injured, paralyzed or killed in an accident if you ignore this warning.

Inspection & Crash Damage Of Carbon Frames/Forks

After A Crash Or Impact:

Inspect frame carefully for damage (See PART II, Section D. Inspect For Safety in your <u>Cannondale Bicycle Owner's Manual</u>.

Do not ride your bike if you see any sign of damage, such as broken, splintered, or delaminated carbon fiber.

Any of the following may indicate a delamination or damage:

- An unusual or strange feel to the frame
- · Carbon which has a soft feel or altered shape
- · Creaking or other unexplained noises,
- Visible cracks, a white or milky color present in carbon fiber section

Continuing to ride a damaged frame increases the chances of frame failure, with the possibility of injury or death of the rider.

Intended Use



The intended use of all models is ASTM CONDITION 4, All-Mountain.

Understand your bike and its intended use. Using your bike the wrong way is dangerous.

Please read your <u>Cannondale Bicycle</u> <u>Owner's Manual</u> for more information about Intended Use and Conditions 1-5.

Servicing

WARNING


This supplement may include procedures beyond the scope of general mechanical aptitude.

Special tools, skills, and knowledge may be required. Improper mechanical work increases the risk of an accident. Any bicycle accident has risk of serious injury, paralysis or death.

To minimize risk we strongly recommend that owners always have mechanical work done by an Authorized Cannondale Dealer. Trigger / Jekyll - Owners Manual Supplement

Maximum Fork Length

Maximum Fork Length is an important frame safety testing specification for front suspension mountain bikes. You must observe the measurement when installing headset parts, headset adapters, installing and adjusting a fork, and selecting replacement forks.



You must select a replacement fork not only based on head tube diameter but the critical factor of frame maximum fork length. Do not exceed maximum fork length. Exceeding the MAXIMUM FORK LENGTH limit can overload the frame causing it to break while riding.

Your retailer MUST follow and observe this specification for your bike. For Maximum Fork Length specifications for Cannondale bicycles, see <u>www.cannondale.com</u>

You can be severely injured, paralyzed or killed in an accident if you ignore this warning.

Tire Size x Maximum Width

Observe the Tire Size x Maximum Width for your bike found in the "Specifications" page of this manual.

Mounting the wrong size tires can result in the tires hitting the fork or frame when riding. If this happens, you can lose control of your bike and you can be thrown off, a moving tire can be stopped because it touches the fork or frame.

Do not mount oversized tires, ones that rub or hit the fork or frame, ones that result in too little clearance, or ones that can hit the fork or frame when the suspension is fully compressed or when riding.

Take care that the tires you select are compatible with your bike's fork or frame design. Also, be sure to follow the manufacturer's recommendations of your front fork and rear shocks.

When you are considering tires for your bike consider...

The actual measured size of a tire may be different than its sidewall marking. Each time you mount a new tire, take the time to inspect the actual clearance between the rotating tire and all parts of the frame. The U.S. Consumer Product Safety Commission (CPSC) requires at least 1/16" (1.6 mm) tire clearance from any part of the bike. Allowing for lateral rim flex and a wheel or rim that is out-of-true will likely mean choosing a rear tire that provides even more clearance than the CPSC recommends.

Ask your dealer for the right tires for your bike and its particular components!

You can be severely injured, paralyzed or killed in an accident if you ignore this warning.

Trigger / Jekyll - Owners Manual Supplement

Rear Shocks

WARNING

Select only compatible shocks and forks for your bike. Do not modify your bike in any way to mount one.

Have your shock or fork installed by a professional bike mechanic

Riding with the wrong rear shock can damage the frame. You could have a serious accident. Make sure the total travel, eye-to-eye length, and stroke length of the rear shock you select meet the "Specifications" listed in this manual.

When selecting different shocks or forks for your bike, make sure that the shock or fork you select is compatible with your bike's design and how you will use your bike.

You can be severely injured, paralyzed or killed in an accident if you ignore this warning.

Minimum Seat Post Insert

Make sure at least 100 mm of the seat post is inserted into the frame at all times.

Failure to insert the seat post at least 100 mm can place a very high stress on the seat tube top tube junction causing the frame to fail while riding.

Remove the seat post. Measure 100 mm from the bottom of the seat post. Use a permanent marker to mark the post at 100 mm.

When adjusting the seat post height in the seat tube, never adjust the seat post so that the line you mark is above the top edge of the seat tube.

You must also be aware that bicycle seat posts are permanently marked by the manufacturer with a "minimum insert" line on the seat post itself. You must not rely on this marking as an indication of the proper minimum seat post insertion depth.

You can be severely injured, paralyzed or killed in an accident if you ignore this warning.

TECHNICAL INFORMATION

Specifications - Trigger 27.5

Item	Specification
Rear Travel	Hustle Mode: 115 mm Flow Mode: 145 mm
Head Tube	UPR: 1 -1/8 in, LWR: 1-1/2 in
Headset	FSA Orbit C-40-ACB w/9.1 mm stack
Bottom Bracket Type/ Width	PF30 / 83 mm
Front Derailleur	Low Direct Mount, Side Swing (alloy CS only)
Seat Post Dia./Binder	31.6 mm / 34.9 mm
▲ Min. Seat Post Insert	100 mm
▲ Tire Size/ Max Tire Width	27.5 in x 2.5 in (measured)
A Max. Fork Length	545 mm
Rear Shock: Eye-To-Eye / Stroke / Bushing Width	210 mm / 55 mm / FT: 30 x 8 mm, RR: 30 x 8 mm
Sag	30%, 17 mm
Chain Guide	ISCG 05
Rear Brake: Mount Type / Min/Max Rotor Dia.	Flat Mount / 160 mm / 180 mm
Rear Axle	Maxle TA / 148 x 12 mm, 180 mm length
Ai Offset	Rear Wheel: 3 mm Offset to NDS SRAM Chainring: +6 mm Offset Hollowgram SpideRing: Ai Offset
▲ Intended Use	ASTM CONDITION 4, All-Mountain
▲ Max. Weight Limit Total (rider+all equipment):	305 lbs / 138 kg


Specifications - Jekyll 27.5

Item	Specification
Rear Travel	Flow Mode: 165 mm, Hustle Mode: 130 mm
Head Tube	UPR: 1 -1/8 in, LWR: 1-1/2 in
Headset	FSA Orbit C-40-ACB w/ 9.1 mm stack
Bottom Bracket: Type/ Width	CRB: PF30 / 83 mm, ALLY: BB30 / 83 mm
Front Derailleur	N/A
Seat Post: Dia./Binder	31.6 mm / 34.9 mm
▲ Min. Seat Post Insert	100 mm
▲ Tire Size x Max. Width	27.5 in x 2.5 in (measured)
▲ Max. Fork Length	CRB: 565 mm, ALLY: 565 mm
Rear Shock: Eye-To-Eye / Stroke / Bushing Width	230 mm / 60 mm /FT: 30 x 8 mm, RR: 30 x 8 mm
Sag	30%, 18 mm
Chain Guide	ISCG 05
Rear Brake: Mount Type / Min/Max Rotor Dia.	Flat Mount / 160 mm / 180 mm
Rear Axle: Type/Length	Maxle TA /148 x 12 mm, 180 mm length
Ai Offset:	Rear Wheel: 3mm Offset to NDS, SRAM Chainring: +6 mm Offset Hollowgram SpideRing: Ai Offset
▲ Intended Use	ASTM CONDITION 4, All-Mountain
▲ Max. Weight Limit Total (rider+all equipment):	305 lbs / 138 kg

Specifications - Jekyll 29

Item	Specification
Rear Travel	Flow Mode: 150 mm Hustle Mode: 120 mm
Head Tube	UPR: 1 -1/8 in, LWR: 1-1/2 in
Headset	FSA Orbit C-40-ACB w/ 9.1 mm stack
Bottom Bracket: Type/ Width	PF30 / 83 mm
Front Derailleur	N/A
Seat Post: Dia./Binder	31.6 mm / 34.9 mm
▲ Min. Seat Post Insert	100 mm
▲ Tire Size x Max. Width	29 in x 2.5 in (measured)
A Max. Fork Length	565 mm
Rear Shock: Eye-To-Eye / Stroke / Bushing Width	230 mm / 60 mm /FT: 30 x 8 mm, RR: 30 x 8 mm
Sag	30%, 18 mm
Chain Guide	ISCG 05
Rear Brake: Mount Type / Min/Max Rotor Dia	Flat Mount / 160 mm / 180 mm
Rear Axle: Type/Length	Maxle TA / 148 x 12 mm, 180 mm length
Ai Offset:	Rear Wheel: 3 mm Offset to NDS SRAM Chainring: +6 mm Offset Hollowgram SpideRing: Ai Offset
▲ Intended Use	ASTM CONDITION 4, All-Mountain
▲ Max. Weight Limit Total (rider+all equipment):	305 lbs / 138 kg

Trigger / Jekyll - Owners Manual Supplement




Dimensions = centimeter

Geometry - Trigger

Frar	ne Size	S	М	L	XL
А	Seat Tube Length	40.0	43.0	46.0	52.0
В	Top Tube Horizontal	57.6	60.2	62.7	65.5
С	Top Tube Actual	-	-	-	-
D	Head Tube Angle	66°	*	*	*
Е	Seat Tube Angle Effective	74.5°	*	*	*
F	Standover	75.0	76.0	76.5	79.5
G	Head Tube Length	9.7	11.0	12.2	13.5
Н	Wheelbase	113.6	116.4	119.0	122.0
I	Front Center	71.6	74.4	77.1	80.0
J	Chain Stay Length	42.0	*	*	*
К	Bottom Bracket Drop	1.2	*	*	*
L	Bottom Bracket Height	34.5	*	*	*
М	Fork Rake	4.4	*	*	*
Ν	Trail	10.1	*	*	*
0	Stack	57.6	58.8	59.9	61.0
Ρ	Reach	41.6	43.9	46.1	48.6

All Specifications subject to change without notice.

* - Indicates same.



Dimensions = centimeter


Geometry - Jekyll

	j i j		Jeky	yll 29			Jekyl	l 27.5	
Fran	ne Size	S	М	L	XL	S	М	L	XL
Α	Seat Tube Length	40.0	43.0	46.0	52.0	40	43	46	52
В	Top Tube Horizontal	58.6	61.1	63.6	66.4	58.4	60.9	63.4	66.2
С	Top Tube Actual	56.8	58.9	61.3	64.1	53.7	56.2	58.7	62.1
D	Head Tube Angle	65°	65°	65°	65°	65°	*	*	*
Е	Seat Tube Angle Effective	75°	75°	75°	75°	75.0°	*	*	*
F	Standover	76.0	76.6	77.6	78.8	75	75.8	76.7	77.5
G	Head Tube Length	10.2	11.5	12.7	14.0	10.2	11.5	12.7	14
Н	Wheelbase	117.9	120.7	123.4	126.4	116	118.7	121.4	124.4
Ι	Front Center	73.8	76.5	79.2	82.3	74	76.7	79.4	82.4
J	Chain Stay Length	44.2	*	*	*	42	*	*	*
К	Bottom Bracket Drop	1.6	1.6	1.6	1.6	0.8	*	*	*
L	Bottom Bracket Height	36.0	36.0	36.0	36.0	34.9	*	*	*
М	Fork Rake	4.2	*	*	*	4.4	*	*	*
Ν	Trail	13.0	*	*	*	11.4	*	*	*
0	Stack	59.8	61.0	62.1	63.3	59.2	60.4	61.5	62.6
Ρ	Reach	41.9	44.0	46.2	48.7	42.5	44.7	46.9	49.4

All Specifications subject to change without notice.


* - Indicates same.

Guards/Protectors - Placement




Chainstay Left (outer)


Chainstay Right (outer)




NOTICE

Damaged, loose, missing, incorrectly, or positioned protectors can lead to frame damage. Damage of this type is not covered by the Cannondale Limited Warranty. Make sure all frame protectors and guards are present, installed correctly and are in good condition.







Downtube


wider end toward bottom bracket


Center on tube



Trigger / Jekyll - Owners Manual Supplement

Dropout





Maintenance

The condition of the bearings, pivot axles, and spacers should be inspected periodically. These are normal wear parts so plan to have them renewed as they wear-out.

Inspection frequency should be based upon how and where you ride. Evidence of damage would be excessive play, visible wear, or perhaps corrosion of bearings.

If you find any damage to the parts, discontinue riding until all the parts (bearings, pivot axles, spacers) can be renewed. This will help prevent damage elsewhere.

See the kits list in the back of this supplement for renewal kits.

Key Information:

A special service tool **KP169**/ contains parts necessary to service the assembly. The parts of this tool are shown shaded above.

When connecting the seat stays to the dropouts, always insert the small end of pivot spacers into the dropout bearings . The flat side of the spacers should face out, as shown.

When tightening the axles, insert the 5 mm hex key completely into the axle to prevent damage when turning the bolt. Always tighten with a torque wrench to the specified torque.

Asymmetric Integration - Ai Rear Wheel- 3 mm Offset

The Ai rear hub is offset 3 mm to the drive side. This both aligns the cassette with the Ai frame's 55mm chainline, and aligns the rim/tire with frame's centerline for correct tire clearance.

Ai wheels have equal spoke angles and tension on both sides (non-dished wheel) which improves wheel stiffness, strength.

- The 3mm offset is for 148 X 12mm spacing only!
- Other Ai equipped bike with 142mm or 135mm rear spacing use a 6mm offset.

NOTICE

USE ONLY 3mm "Ai" OFFSET REAR WHEELS.

Incorrect wheel offset can damage your frame.


Standard wheel assembled on this frame will result in insufficient tire clearance leading to rubbing and serious frame damage. This kind of damage is not covered by the Cannondale Limited Warranty.

Building/Truing a Wheel

If you chose to build, or true the wheel, make sure the 3 mm offset is present. Consult with your Cannondale Dealer if you have any questions.



Main Pivot Bearing Tool - CK9017U00OS



LockR

Be sure to support the bike or swingarm to prevent personal injury or bike damage when removing/disconnecting linkages of an axle.

To remove the LockR from the frame:

- 1. Loosen the screw 4-6 turns using a T25 Torx key.
- 2. Tap head of screw with a rubber mallet to un-seat the wedge bolt located on the opposite side..
- 3. Remove the screw and wedge bolt from the still installed axle.
- 4. If it did not come out with the screw, insert a 5 mm hex key and turn to free and remove it. If wedge still sticks insert a wooden or plastic dowel into the drive side and drive it out.
- 5. To remove the axle itself, on non-drive side, insert a 6 mm hex key into the axle on the non-drive side and and turn counter-clockwise until it can be removed.

To install the LockR from the frame:

1. Disassemble and clean all parts of the LockR axle. Do not install it assembled.


Inspect the parts for damage (burrs, scratches, deformity, wear). Replace the entire LockR assembly if any damage is found.

- 2. Apply a light coating of a high-quality bicycle bearing grease to all parts.
- 3. Align the linkage and bearing and insert the threaded end of the pivot axle (1) into the non-drive side.
- 4. Tighten the inserted pivot axle to 1 Nm using a 6 mm hex key fitted torque wrench from the non-drive side.

NOTICE

Use a calibrated torque wrench. Exceeding 1 $N \cdot m$ will result in permanent damage to the LockR pivot system.

- 5. Insert the wedge bolt (2) into the drive side of the axle and insert the small end of the wedge (3) into the non-drive side axle head.
- 6. Thread the screw (4) into wedge bolt with a wrench and tighten to 5.0 Nm.





Trigger / Jekyll - Owners Manual Supplement

Tightening Torques

Correct tightening torque for the fasteners (bolts, screws, nuts) on your bicycle is very important to your safety, durability, and performance of your bicycle.

We urge you to have your dealer correctly torque all fasteners using a torque wrench. If you decide to tighten fasteners yourself always use a calibrated torque wrench!





Rear Derailleur Hanger - *CK3257U00OS*


Hanger Replacement

Hanger replacement kit is available as Cannondale kit - CK3257U00OS.

The kit includes the hanger (1) and a new pivot bolt (3). Before installing a new hanger, be sure to clean any dirt or debris on the dropout with a nylon brush (old toothbrush). Inspect the area for any damage. Lightly grease the dropout surface. Apply Loctite 242 (blue) to the pivot bolt (4). Align the hanger on the opposite side of the dropout and tighten the bolt to the specified torque.

Trigger / Jekyll - Owners Manual Supplement

Shimano Di2 Battery



Battery Installation

For Di2, use the seat post type battery (Shimano SM-BTR2)

- 1. Remove fork and headset from the frame.
- Attach mounting plate (1) included in Cannondale kit K32027/ to the battery (2) using two 3mm nylon ties (3). Make sure the plate lip (a) is aligned with the case groove on the battery nearer the cable connection (b). See inset A.
- 3. Tie a thin dental string (5) to the battery plate
- 4. Plug in Di2 wire (to junction B) into the battery
- 5. Use a shift cable inserted into the top tube hole and out the lower head tube to guide.


- Attached the end of the dental thread to the shift cable and draw the dental thread through and out the top tube hole.
- Insert the battery and plate in the bottom of the head tube and use the dental thread to guide the battery and plate into position. 5. With the battery in position as shown, holding the string (5) taught, apply grease to the screw (6) and tighten to 2 Nm.


The screw threads should cut the string so it can be removed.

NOTICE

Periodically, check for proper tightness of the mounting screws. Use a torque wrench. Do not over-tighten.

Internal Guides - KP436/






Internal Frame Guides:


Install plastic spiral wire wrap (5) over Di2 wires (6) passing through internal guide (7).

Use the 4mm guide opening for Di2 wire.



Trigger / Jekyll - Owners Manual Supplement

Gemini Rear Shock



Flow Mode

Flow mode uses the shock's entire air chamber and is ideal for descending and other situations where having full shock travel is advantageous.

Set to Flow mode: press the black handlebar remote button (a) releasing the silver button (b).



Hustle Mode

This mode reduces the usable air volume in the shock and provides a more supportive, progressive spring rate for situations like out of the saddle sprinting and climbing.

To switch the shock to Hustle mode, press the silver button down until you feel a click and the silver button remains depressed.





To set air pressure:

 Set handlebar remote to Flow mode: press the black handlebar remote button (a) so that the remote handlebar control is in the position shown below.



- 2. Remove the Schrader valve cap (1) and pressurize the shock with a shock pump.
- 3. Remove the shock pump.
- 4. Cycle the shock 10 times to allow the positive and negative air pressures to equalize.
- NOTE: Air pressure measured at the pump will decrease after air has transferred from positive to negative chambers.
- 5. Check sag to confirm your shock setup. Recommended seated sag with full riding gear is 30%

- If there is too much sag, add air pressure in 10 psi increments until correct sag is achieved. If there is too little sag, reduce air pressure in 10 psi increments until correct sag is achieved.
- 7. Install the Schrader valve cap onto the air valve.
- 8. Turn the red rebound adjuster clockwise towards "slow" until it stops.
- a. Float X Insert a 2mm hex wrench into a cutout in the red rebound knob located near the eyelet on the frame side of the shock. Use the wrench to turn the knob towards "slow" until it stops.
- b. Float DPS Turn the red rebound knob located under the blue compression adjustment lever on the frame side of the shock clockwise towards "slow" until it stops.
- Turn the red rebound knob counter-clockwise towards "fast", counting each detent click until you reach the recommended number of clicks based on the table below.

Trigger / Jekyll - Owners Manual Supplement

Remote Cable Installation

- Cut a piece of derailleur housing that fits from Gemini's housing stop to the Gemini remote without interfering with the rotation of the handle bars. Install a ferrule on one end of the housing.
- 2. Place the Gemini remote in Flow mode by pressing the black button on the Gemini remote while placing upward pressure on the silver button.
- 3. Insert a derailleur cable into the round hole below the silver button on the Gemini remote. Feed the cable through the remote until the cable head is fully seated.
- Insert the cable into the cable noodle end opposite the barrel adjuster. Slide the cable noodle along the cable until it is fully inserted into the remote.
- 5. Insert the derailleur cable into the Gemini cable housing end with the ferrule and push it through until the housing is fully seated in the barrel adjuster on the cable noodle.
- 6. Insert the derailleur cable through the housing stop on the Gemini shock, then pull the cable until the housing is fully seated in the housing stop. There should not be a housing ferrule on this side of the Gemini housing.

- 7. Use a 2 mm hex wrench to loosen the set screw located on the rear of the Gemini shock cam until there are only 2 threads engaged.
- 8. Insert the cable between the set screw and Gemini cam. Pull the cable so the cable and housing are fully seated and tight.
- 9. Tighten the set screw to 1.2 Nm with a 2mm hex wrench to secure the cable.
- 10. Function Test: Push on the remote's silver Hustle mode button, then press the black Flow mode button.
- a. Cable is too tight: the remote cannot stay in Hustle mode. Reduce cable tension by turning barrel adjuster clockwise. If problem persists, reduce cable tension by loosening the set screw and resetting cable tension as described in steps 7-9.
- b. Cable is too loose: the cam will not turn as soon as you engage the lever. Increase cable tension by turning the barrel adjuster counter-clockwise. If problem persists increase cable tension by loosening the set screw and resetting cable tension as described in steps 7-9.

MAINTENANCE

The following table lists only supplemental maintenance items. Please consult your <u>Cannondale Bicycle Owner's Manual</u> for more information on basic bike maintenance.

Item	Frequency
Cable Routing - Make sure control cables are in place, undamaged and attached securely.	Before first ride
Frame Protection - Check the various frame protectors (downtube, headtube, chainstay, swingarm on your bike. Make sure they are in place and in good condition.	
Damage Inspection - Clean and visually inspect entire bike frame/swing arm/linkage assembly for cracks or damage.	Before and after each ride
Check Tightening Torques - In addition to other component specific tightening torques for your bike. tighten according to the "Tightening Torques" information listed in this supplement.	Every few rides
Disassemble, clean, inspect, re-grease, replace worn or damaged parts in the following assemblies:	In wet, muddy, sandy conditions every 25 hrs.
Shock Link Pivot Axles Frame Pivot Bearings	In dry, conditions every 50 hrs.

Fork and Shock- Consult the manufacturer's owner's manual for maintenance requirements.


Any part of a poorly maintained bike can break or malfunction leading to an accident where you can be killed, severely injured or paralyzed.

Frequent checks are necessary to identify the problems that can lead to an accident. See "Inspect For Safety" in your <u>Cannondale Bicycle Owners Manual.</u>

Trigger / Jekyll - Owners Manual Supplement


REPLACEMENT PARTS

Trigger 27.5



ID	Part Number	Description	CRB	ALLY
А	CK3147U00OS	Trigger Pivot HDWE	~	~
В	CK3177U00OS	Trigger Pivot BRGS	~	~
С	CK3227U00OS	Trigger Shock MNT HDWE	~	~
D	CK3257U00OS	RD HGR TA ST SS 015	~	~
-	KP421/160	Brake MNT Flat 160 mm	V	~
Е	KP421/180	Brake MNT Flat 180 mm	~	~
F	CK3237U00OS	Trigger CRB CS Protector	V	
G	CK3287U00OS	Trigger CRB CS Guard	~	

ID	Part Number	Description	CRB	ALLY
	К34068	Trigger CRB CS Heel Rub GRDS	~	
н	К34058	Trigger ALLY CS Heel Rub GRDS		~
I	CK3247U00OS	Trigger ALLY CS Protector	~	~
J	K36139	Trigger Suspension Link 27.5 BLK	~	~
к	KP390/	FT Derailleur Spacer MNT	~	~




ID	Part Number	Description	CRB	ALLY
L	CK9017U00OS	17x30 Bearing Tool	~	~
М	KP388/	Seatbinder MTN 34.9	~	~
	CK3117U00SM	Trigger CRB DT Protec- tor SM	r	
	CK3117U00MD	Trigger CRB DT Protec- tor MD	r	
0	CK3117U00LG	Trigger CRB DT Protec- tor LG	r	
	CK3117U00XL	Trigger CRB DT Protec- tor XL	~	

ID	Part Number	Description	CRB	ALLY
Р	CK3187U00OS	Jekyll/Trigger Grommets	~	~
Q	KP436/	Modular CBL Guides HT DT BB	~	
R	KP197/SRM	PF30 BB Cups And Bearings	~	~
S	KB6180/	BB30 Bearing Blue (QTY 2)	~	~
Т	K22037	BB30 Bearing Blue (QTY 24)	~	~

Trigger / Jekyll - Owners Manual Supplement


REPLACEMENT PARTS

Jekyll 29



ID	Part Number	Description
А	CK3157U00OS	Jekyll Pivot HDWE
В	CK3167U00OS	Jekyll Pivot BRGS
С	CK3207U00OS	Jekyll CRB Shock Mount HDWE
D	K36119	Jekyll Suspension Link 29 BLK
Е	CK3257U00OS	Derailleur Hanger TA ST SS 015
F	CK3217U00OS	Jekyll Al Chain Stay Protector

ID	Part Number	Description			
G	K34058	Jekyll/Trigger Alloy CS Heel Rub Guard			
	KP421/160	Brake MNT Flat 160 mm			
	KP421/180	Brake MNT Flat 180 mm			




ID	Part Number	Description
Р	CK3187U00OS	Jekyll/Trigger Grommets
М	KP388/	Seatbinder MTN 34.9
н	KP436/	Modular CBL Guides HT DT BB
к	CK9017U00OS	17x30 Bearing Tool

ID	Part Number	Description	
	K34088SM	Jekyll CRB DT Protector, SM	
	K34088MD	Jekyll CRB DT Protector, MD	
L	K34088LG	Jekyll CRB DT Protector, LG	
	K34088XL	Jekyll CRB DT Protector, XL	
R	KP197/SRM	PF30 BB Cups And Bearings	
S	KB6180/	BB30 Bearing Blue (QTY 2)	
Т	K22037	BB30 Bearing Blue (QTY 24)	


Trigger / Jekyll - Owners Manual Supplement

Jekyll 27.5



ID	Part Number	Description	CRB	ALLY
А	CK3157U00OS	Jekyll Pivot HDWE	~	~
В	CK3167U00OS	Jekyll Pivot BRGS	V	~
с	CK3207U00OS	Jekyll CRB Shock MNT HDWE	~	
	K36018	AL Frame Shock MNT HDWE		~
D	CK3187U00OS	Jekyll/Trigger Grommets	V	~
Е	KP388/	Seatbinder MTN 34.9	~	~
F	KP436/	Modular CBL Guides HT DT BB	V	

ID	Part Number	Description	CRB	ALLY
	K34088SM	Jekyll CRB DT Protector, SM	V	
	K34088MD	Jekyll CRB DT Protector, MD	~	
н	K34088LG	Jekyll CRB DT Protector, LG	~	
	K34088XL	Jekyll CRB DT Protector, XL	~	
	K34008	Jekyll ALLY DT Protector, All sizes		~
1	CK9017U00OS	17x30 Bearing Tool	~	~
к	CK3217U00OS	Jekyll ALLY CSTAY Protector		~
L	CK3197U00OS	Jekyll CRB CSTAY Protector	V	



ID	Part Number	Description	CRB	ALLY
м	K34078	Jekyll CRB Chainsuck Protector	~	
Ν	K36129	Jekyll Suspension Link 27.5 BLK	~	~
0	K34068	Jekyll CRB CS Heel Rub GRDS	~	
	K34058	Jekyll ALLY CS Heel Rub GRDS		~

ID	Part Number	Description	CRB	ALLY
	KP421/160	Brake MNT Flat 160 mm	~	~
P	KP421/180	Brake MNT Flat 180 mm	~	~
W	CK3257U00OS	RD HGR TA ST SS 015	~	~
R	KP197/SRM	PF30 BB Cups And Bearings	~	
S	KB6180/	BB30 Bearing Blue (QTY 2)	~	~
Т	K22037	BB30 Bearing Blue (QTY 24)	~	~
	QC616/	Circlips BB Si (QTY 2)		~

Trigger / Jekyll - Owners Manual Supplement

NOTES

Use this page to write /record important information about your bike : (e.g. maintenance history, dealer contact information, settings, etc.)

WWW.CANNONDALE.COM

© 2019 Cycling Sports Group Trigger/Jekyll Owner's Manual Supplement 134942 Rev. 1

CANNONDALE USA

Cycling Sports Group, Inc. 1 Cannondale Way, Wilton CT, 06897, USA 1-800-726-BIKE (2453) www.cannondale.com

CANNONDALE EUROPE

Cycling Sports Group Europe, B.V. Hanzepoort 27, 7575 DB, Oldenzaal service@cyclingsportsgroup.com

CANNONDALE UK

Cycling Sports Group Vantage Way, The Fulcrum, Poole, Dorset, BH12 4NU +44 (0)1202732288 sales@cyclingsportsgroup.co.uk