

### Rack Removal Instructions

The front rack is attached to the bicycle at three places: the fork crown and on both fork legs. **See Figure 1**

You will not have to disassemble the rack.

You may need the following tools:

- 5 mm allen wrench
- 8 mm regular wrench (or adjustable wrench)
- Philips head screwdriver

Please also visit the Recalls & Notices section of [cannondale.com](http://cannondale.com) for a video of these instructions.

#### To remove the rack:

1. Lean the seat of the bike against a wall or other stable object, so the bike cannot fall over or move while you are removing the rack.

2. Find the bolts that secure the rack struts to the fork legs, as shown in **Figure 2**.

Use the appropriate tool to turn the bolts counter-clockwise until you can remove the bolt and the washer under it from both fork legs.

3. Find the bolt at the top of the fork that secures the rack bracket, as shown in **Figure 3**.

Use the appropriate tool to turn the bolt counter-clockwise until you can remove the bolt and the washer under it.

When this bolt has been removed, lift the rack up and forward to remove it.

4. Store the removed rack for later re-installation by a Cannondale dealer, once we have received governmental approvals to conduct a recall to replace the rack mounting hardware.

